



WORKING PRINCIPLE - CONFIGURATION



■ COMPRESSOR


COMPRESSED AIR IS DIRECTED VIA AIR FILTER TO PRESSURE VESSEL



■ PRESSURE VESSEL

COMPRESSED AIR PRESSES THE LIQUID OUT... TO:

■ ... TO VALVES, GLUE GUNS, EQUIPMENTS, ETC:



PAKARTE LLC
Mob +372 5656 9482
pakarte@pakarte.com
www.pakarte.com